



1. 环切外护套 15mm 左右；  
Circumcising outer sheath about 15mm



2. 套后外壳、电缆夹  
Back cover, cable clamp



3. 将编织线向后弯折，漏出电缆锡箔层  
Bend the braided wire backwards to leak the tin foil layer of the cable



4. 在电缆编织丝和锡箔层之间插入内芯  
Insert the inner core between the cable braided wire and the tin foil layer



5. 紧贴内芯端面切电缆除锡箔层和绝缘层，漏出内导体  
Cut the cable close to the end face of the inner core, except for the tin foil layer and insulation layer, and the inner conductor leaks



6. 套入前外壳  
Set into the front shell

